

mod. Hydrosonis-ULC

Note: In the text below, the term meter refers both to the heat meter and to the cooling meter and the combined heat and cooling meter, unless otherwise specified.

1. General

1.1 Use

The HYDROSONIS-ULC is used as a meter for heating or cooling consumption measurement in systems with water. The meter consists of a volume measurement unit, two fixed temperature sensors and an electronic unit that calculates the energy consumption based on volume and temperature difference.









Note: The meter cannot be opened without damaging the security seal.

1.2 General notes

The meter left the factory in a faultless condition where safety is concerned. The manufacturer will provide additional technical support on request. Calibration relevant security seals on the meter must not be damaged or removed. Otherwise, the warranty and calibration validity of the meter will no longer apply.

- Keep the packaging so that you can transport the meter in its original packaging following expiry of the calibration validity.
- Lay all cables at a minimum distance of 500 mm to high voltage and high frequency cables.
- A relative humidity of < 93 % at 25 °C is permissible (without condensation).
- Avoid cavitation in the whole system due to overpressure i.e. at least 1 bar at qp and approx. 2 bar at qs (applies for approx. 80 °C).

• Safety informations

-  The meters may only be used in building service engineering plants and only for the applications described.
-  The local regulations (installation etc.) must be adhered to.
-  The operating conditions according to the type plate must be complied with during use. Non-compliance can result in hazardous situations and the expiry of all claims arising from liability for defects as well as liability on the basis of any expressly granted guarantees.
-  The meter is only suitable for circulating water in heating systems.
-  The meter is not suitable for drinking water.
-  Beware of sharp edges on thread, flange and measuring section.
-  Requirements for circulating water (CEN/TR 16911: 2016).
-  Only personnel, trained in the installation and operation of meters in heating and cooling systems, may install and remove the meter.



Only install or remove the meter when the pipes are pressure-less.



After installing the meter, check the leak-tightness of the system.



Guarantee and calibration validity will lapse if the calibration relevant security seal is broken.



Only clean the meter from outside with a soft, lightly wetted cloth. Do not use any spirit or cleaning solvent.



As far as disposal is concerned, the meter is a waste electronic appliance in the sense of European Directive 2012/19/EU (WEEE) and it must not be disposed of as domestic waste. The relevant national, legal regulations must be observed as the appliance must be disposed of via the channels provided for this purpose. The local and currently valid legislation must be observed.



The meter contains lithium batteries. Do not dispose of the meter and the batteries with domestic waste. Observe the local stipulations and laws on disposal.



You can return the lithium batteries to the manufacturer for appropriate disposal following use. When shipping please observe legal regulations, in particular, those governing the labelling and packaging of hazardous goods.



Do not open the batteries. Do not bring batteries into contact with water or expose to temperatures above 80 °C.




The meter does not have any lightning protection. Ensure lightning protection via the in-house installation.



3. Installation

To install the meter proceed as follows:

- Determine the place of installation in line with the inscription on the meter.




Note: At a heating meter  or combined heat/cold meter the mounting place of the flow sensor cold

side is equivalent to return . The mounting place of the flow sensor hot side is equivalent to flow .



Note: At a cooling meter  the mounting place of the flow sensor hot side is equivalent to the return .

The mounting place of the flow sensor cold side is equivalent to flow .

- Observe the dimensions of the meter and check whether there is sufficient space available.
- Rinse the system thoroughly before installing the meter.
- Fit the meter vertically or horizontally between two slide valves so that the arrow on the housing and the flow direction match. Also observe the installation situations and the following examples of installation.
- Fit the temperature sensors in the same circuit as the meter. Please observe admixtures.

- Seal the temperature sensor and the fittings to protect against manipulation.
- If you install the meter for cooling metering, follow the appropriate notes.

Recommendation: If you are installing several meters, the same installation conditions must be consistent for all meters.

Installation notes

Note: When installing the meter, the locally applicable installation regulations for meters must be observed.

Inlet or outlet sections are not necessary. If you install the meter in the common return of two circuits, determine a place of installation with a minimum distance of $10 \times DN$ from the T-piece. This distance ensures a good mixing of the different water temperatures. You can install the temperature sensors in T-pieces, ball valves, directly immersed or in pockets depending on the version. The temperature sensor ends must reach to at least the middle of the pipe cross section.


Note: Protect the meter against damage through impacts or vibrations at the place of installation.

Note: Ensure the electronic unit is protected against any ingress of water.

Recommendation: Do not install the meter on the intake side of a pump. Maintain a minimum distance of $10 \times DN$ on the outlet side.

Examples of installation (directly immersed sensor)

You can install the meter in any position e.g. vertically or horizontally. In order to avoid accumulation of air and disruption in operation, fit the meter in a vertical installation position and not in the uppermost area of a pipeline.



* This position is not permitted for cold meters and in cases where moisture can enter the electronic unit due to condensation (e.g. during an interruption in the summer).

Fig. 1




Fig. 2: Example for installation with ball valve and meter with 110 mm armature




Fig. 3: Installation for circulation with admixing; placement of temperature sensors




Fig. 4: Installation for circulation with throttling configuration for example (flow sensor in flow direction before control valve / differential pressure regulating valve)

Installation notes for sensor adapter set

A mounting set is included for meters with 5.2×45 mm temperature sensors. With this you can fit the temperature sensor directly immersed into an insert or a ball valve for example.

1. Use the fit-up aid/pen provided to mount the O-ring at the installation point.
2. Place both halves of the plastic bolting round the 3 notches of the temperature sensor.
3. Press the bolting together and screw the bolting hand tight into the installation point up to the stop (tightening torque 3 ... 5 Nm).




Fig. 5: Mounting adapter set

3.1 Installation of cooling meters and combined heat/cooling meters

Observe the following installation instructions to avoid condensation water.

- Mount the cooling meter so that the black cover on the measuring section points sideways or downwards.
- Mount the electronic unit separated from the volume measuring unit e. g. on the wall.
- Form a loop downwards with the connected cables.
- Mount the protection pocket so that the temperature sensor stands vertically downwards or horizontally.
- Mount the temperature sensor horizontal or vertical in the pipe from below.




Fig. 6: Recommended mounting position for cooling measurement

3.2 Electronic unit

The ambient temperature of the electronic unit must not exceed 55°C . Avoid direct sunlight.

Mount the electronic unit separated from the volume measurement unit e. g. on the wall if the water temperatures are below 10°C and above 90°C .

Aligning electronic unit

Proceed as follows to align the electronic unit:

- Turn the electronic unit to the left or right through 90° or through 180° as required.

Note: When turning through 45° the electronic unit is not connected tightly to the volume measurement unit.

Wall fitting (split fitting)

Proceed as follows for the wall fitting:

- Turn the electronic unit through 45°.
- Pull the electronic unit away from the volume measurement unit.
- Unscrew the adapter plate from the volume measuring unit.
- Fix the adapter plate on the wall.




Fig. 7: Top view and cross section of the adapter plate

- Place the electronic unit on the wall adapter at an angle of 45° and turn it into position.

3.3 Power supply

The meter is equipped with a long life battery for 6 or 11 years of operation. You can find the operating time on the dial plate.



Warning: Do not open the batteries. Do not bring battery into contact with water or expose to temperatures above 80 °C. Dispose of used batteries at suitable collection points.

3.4 Interfaces and Communication

Note: Frequently switching off the M-bus voltage may result in a reduction of the battery life.

The meter is equipped with an optical interface in accordance with EN 62056-21 as standard.

If the meter is equipped with the option "M-Bus", it is supplied with a 2-wire cable.

If the meter is equipped with the option "pulse", it is supplied with a 4-wire cable.

The connection cable can be extended by fitting a junction box.

3.5 Temperature sensor

Note: Wires must not be separated, shortened or extended.

4. Operating

Note: Both display range and data displayed can differ from this description depending on the appliance parameterization. Certain button functions can also be blocked.

The meter consists of a 7-digit LCD displaying various values.




Fig. 8: LCD

| Number | Description |
|--------|-------------------------------------|
| 1 | Identification previous year value |
| 2 | Previous year value |
| 3 | Maxima |
| 4 | Previous month value |
| 5 | Identification previous month value |
| 6 | Activity display at flow |
| 7 | Calibrated value |

Switching the display

Proceed as follows to switch between the display values:

- Press the button briefly (for less than 2 sec.) to show the next line of the current loop.

After the last line is displayed, the first line comes up again.

- Hold down the button (longer than 3 sec.) in order to display the next loop.

After the last loop is displayed, the first loop comes up again.

If you do not operate the meter for 30 sec. in the user loop "LOOP 0", the meter changes to the standard display. If you do not operate the meter for 30 min. in the loops "LOOP 1 ... 4", the meter changes to the standard display.

User loop "LOOP 0"

| | | | |
|--------------|------------------------------|----------|--|
| LOOP 0 | User loop | *0000000 | Segment test |
| *1234567 kWh | Energy quantity | F:... | In case of error message with error code |
| 1234567 kWh | Cooling registers (optional) | | |
| col d | | | |
| *1234567 m³ | Volume | | |

Current values "LOOP 1"

| | | | |
|----------|---|-----------|--------------------------|
| LOOP 1 | Current values | | |
| 1234 kWh | Current flow | 210 K | Temperature difference |
| 300 kWh | Current heat power | bd 1234 h | Operating time with flow |
| 670 °C | Alternate current temperature hot and cold side in 2 s cycles | Fd 123 h | Missing time |
| 460 °C | | Pd 1234 h | Time with flow |

Previous month's values "LOOP 2"

| | | |
|---------|--|---------|
| LOOP 2 | Previous month's values | |
| 0102.12 | Log date | |
| 1234567 | Amount of energy on set day | 1000 |
| 1234567 | Cooling registers on set day (optional) | 1702.12 |
| cold | Volume on set day | 810 |
| 1234567 | Missing time on set day | 1702.12 |
| Fd 123 | Max. flow on set day in 2 s cycles with date stamp | 660 |
| 3099 | | 1702.12 |
| 1701.12 | | |

General/Communication "LOOP 3"

| | | |
|---------|---------------------------------------|---------|
| LOOP 3 | General/Communication | |
| 1234567 | Device number, 7-digit | 0101-- |
| M-Bus | Optional interface | 01---M1 |
| 127 | Primary address (only for M-Bus) | 17-16 |
| 0000000 | Secondary address 7-digit - for M-Bus | 1702.12 |
| | | 1702.12 |

Other "LOOP 4"

| | | |
|---------|-------|------|
| LOOP 4 | Other | |
| 0802.12 | Date | ---- |
| 105959 | Time | |

4.1 Monthly values

The meter stores the following values for 24 months on the monthly set day

- Missing time
 - Volume
 - Energy
- and the maxima with date stamp for
- Flow
 - Power
 - Temperature hot side
 - Temperature cold side

4.2 Parameterization

When the LCD displays the code input, you can access the parameterization operation by entering the code. You can set date and M-Bus primary address in the parameterization operation for example. For more detail see the separate parameterization instruction.

5. Getting started

For activation proceed as follows:

- Open the slide valves slowly.
- Check the heating system for leak-tightness.
- Vent the heating system carefully.
- Press the button on the meter briefly.

The message "F0" disappears after 10 sec.

- Check the measured values for flow and temperatures for plausibility.

- If needed vent the heating system until the flow display is stable.
- Fit the user locks to the fittings and the temperature sensors. The scope of supply includes two self lock seals for sealing a sensor and the connecting fitting.
- Read the meter status for energy, volume, operation and missing time and note the values.

Error messages for incorrect installation:

| | |
|---------|---|
| FL nEE | Error "incorrect flow direction (negative)" Check that the flow direction arrows on the volume measurement unit match the flow direction of the system. If the directions do not match, turn the volume measurement unit by 180°. |
| dIFFnEE | Error "negative temperature difference" Check whether the sensors are installed in the right circular flow (flow and return flow interchanged). Use only a meter suitable to the mounting place. Heat meter: Temperature sensor in the flow-pipe with higher temperatures; temperature sensor in return-pipe with lower temperature Cooling meter: Temperature sensor in the flow-pipe with lower temperatures; temperature sensor in return-pipe with higher temperature |

6. Functional details

If the respective operation thresholds are exceeded and flow and temperature difference are positive, the meter summates the energy and the volume.

If the operate margin is gone below a "u" is displayed at a leading point for the flow, power and temperature display.

For a positive flow the activity display appears in the user loop in the LCD.

All segments of the display are switched on for control purposes during the segment test. The flow, power and temperature difference are recorded with the appropriate +/- signs. The operating hours are counted from the first connection of the power supply. The meter saves "operating time with flow" as soon as a positive flow is recognized. Missing hours are summated if there is a fault and the meter is thus unable to take a measurement.

Stored maximum values are marked with an „M“ in the lower right hand area of the LCD.

7. Error codes

The meter continuously runs a self-diagnosis and can thus recognize and display various installation or meter errors:

| Error code | Error | Service guidelines |
|---------------------------------------|---|--|
| FL nEG | Incorrect flow direction | Check flow or installation direction; correct if necessary |
| if necessary in exchange with: | | |
| DIFF nEG | Negative temperature difference | Check installation point of the temperature sensors; exchange if necessary |
| if necessary in exchange with: | | |
| F0 | No flow can be measured | Air in the measurement unit/pipe, bleed air from pipe (delivery condition) |
| F1 | Interruption in the hot side temperature sensor | Inform service department |
| F2 | Interruption in cold side temperature sensor | Inform service department |
| F3 | Electronics for temperature evaluation defective | Inform service department |
| F4 | Battery flat | Inform service department |
| F5 | Short-circuit hot side temperature sensor | Inform service department |
| F6 | Short-circuit cold side temperature sensor | Inform service department |
| F7 | Error in the internal memory holding | Inform service department |
| F8 | Errors F1, F2, F3, F5 or F6 for longer than 8 hours, recognition of attempts to manipulate. | Measure dependent on error code. Error message F8 must be reset by service department. |
| F9 | Error in the electronics | Inform service department |

Power Supply

| | |
|----------------------|---------------------------------------|
| Type of power supply | Battery for 6 or 11 years |
| Battery type | AA cell lithium |
| Lithium content | 0,65 g per battery |
| Number of batteries | 1 – 3, depending on the configuration |

| qp m ³ /h | Overall length and connection | | |
|----------------------|-------------------------------|--------------|--------------|
| 0.6 | 110 mm (3/4 ") | | 190 mm (1 ") |
| 1.5 | 110 mm (3/4 ") | 130 mm (1 ") | 190 mm (1 ") |
| 2.5 | | 130 mm (1 ") | 190 mm (1 ") |

8. Technical data



Note: The information on the meter must be observed!

General

| | |
|---|--|
| Measuring accuracy | Class 2 or 3 (EN 1434) |
| Environment class | A (EN 1434) for indoor installation |
| Mechanical class | M1 / M2 *) |
| Electromagnetic class | E1 *) |
| *) according to 2014/32/EU Directive on Measuring Instruments | |
| Ambient humidity | < 93% rel. humidity at 25 °C, without condensation |
| Max. height | 2000 m above sea level |
| Storage temperature | - 20 ... 60 °C |

Electronic unit

| | |
|-------------------------------|-----------------------------|
| Ambient temperature | 5 ... 55 °C |
| Housing protection rating | IP 54 according to EN 60529 |
| Power supply | Battery for 6 or 11 years |
| Operation threshold f. ΔT | 0.2 K |
| Temperature difference ΔT | 3 K ... 80 K |
| Temperature measurement range | 0 ... 180 °C |
| LCD | 7 digit |
| Optical interface | Standard, EN 62056-21 |
| Communication | Optional |
| Separability | Always, cable length 1.5 m |

Temperature sensor

| | |
|-------------------|---|
| Type | Pt 500 according to EN 60751, not detachable |
| Connection type | Pt 500, 2 wire technology |
| Cable length | 1.5 m |
| Construction type | Bolb sensor ø 5.2 × 45 mm; DS direct short, M10 × 27,5 mm |
| Temperature range | 0 ... 105 °C |

Volume measuring unit

| | |
|-----------------------|--|
| Protection class | IP 54 according to EN 60529; optional IP 65 |
| Mounting place | Hot side / cold side |
| Installation position | Any, horizontal or vertical |
| Flow straightening | None |
| Measuring range | 1:100 |
| Temperature range | 5 ... 105 °C |
| | National type approvals may be different. |
| Maximum overload | qs = 2 x qp, permanent |
| Nominal pressure | PN16 (1.6 MPa; PS16) PN25 (2.5 MPa; PS25) |